TM 9-1005-212-12P

OPERATOR AND ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOL LISTS

MACHINE GUNS,
CALIBER .30, M1917A1, M1919A4,
AND M1919A6; MOUNTS, TRIPOD,
MACHINE GUN, M1917A1 AND M2;
AND MOUNT, TRIPOD,
MACHINE GUN—RIFLE, M74



JULY 1964

TAGÓ 5256-C-July

*TM 9-1005-212-12P

TECHNICAL MANUAL No. 9-1005-212-12P HEADQUARTERS DEPARTMENT OF THE ARMY Washington, D.C., 22 July 1964

OPERATOR AND ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOL LISTS

MACHINE GUNS, CALIBER .30, M1917A1, M1919A4 AND M1919A6; MOUNTS, TRIPOD, MACHINE GUN, M1917A1 AND M2; AND MOUNT, TRIPOD, MACHINE GUN—RIFLE, M74

			Page
SECTION	I.	INTRODUCTION	2
	II.	BASIC ISSUE ITEMS LIST	10
	III.	REPAIR PARTS AND SPECIAL TOOL	
		LISTS	33
	IV.	MAINTENANCE ALLOCATION CHART_	74

^{*}This manual supersedes DA Supply Manual ORD 7 SNL A5, 23 April 1957, and DA Supply Manual ORD 7 SNL A6, 23 May 1957.

SECTION I

1. General

- a. This manual is a list of items authorized for operator and organizational maintenance for caliber .30 machine guns M1917A1, M1919A4 and M1919A6; machine gun tripod mounts M1917A1 and M2; and machine gun—rifle tripod mount M74.
- b. Section II is a list of basic issue items. It is composed of those items which make up the major end items of equipment, the tools and repair parts that are issued with the equipment and are required for stockage.
- c. Section III is a list of repair parts and special tools which are required to be stocked by organizational maintenance units as their prescribed load. Also listed are additional items which may be required for performing organizational maintenance but are to be requisitioned, as required.
- d. Section IV contains the maintenance allocation chart for the machine guns and mounts, listing all maintenance and repair operations authorized for all maintenance levels.
- e. For prices of the items listed herein, see the appropriate supply manual of the SM 9-2 series.

Prices of items that are the responsibility of commodity commands may be obtained from appropriate type 2 supply manuals for those services.

f. Additional applications of items in this manual are listed in the supply manuals of the SM 9-3 series.

2. Requisition Notes

a. When requisitioning an item, the requisitioning agency will order the *listed* item. However, the commodity command will take necessary action to issue the exhaust stock item until stock is exhausted, whether it be an individual item, kit, set, or assembly.

b. Requisitions for replacement of items that are the responsibility of commodity commands will be submitted to the commodity command indicated in column 1a, Materiel numerical code.

c. If the exact item requisitioned is not furnished or if other action is necessary, the exact nature of the action taken by the commodity command will be indicated by standard symbols on prescribed forms.

3. Explanation of Columns

a. Source, Maintenance, and Recoverability Code (Col. 1).

(1) Materiel numerical code (col. 1a). This column indicates the materiel numerical code, other than Ordnance materiel, assigned supply responsibility for the listed item. Commodity commands responsible for supply of items in this list are:

Code	Type materiel
3	Chemical Materiel
5	Engineer Materiel
10	Quartermaster Materiel
12	Adjutant General

(2) Source (col. 1b). This column indicates the selection status and source for the listed item. Source codes used in this list are:

Code	Explanation
P	Applies to high mortality parts.
P1	Applies to low mortality parts.
M	Obtain by manufacturing.

(3) Maintenance level (col. 1c). This column indicates the lowest maintenance level authorized to install the item. Maintenance level code used in this list is:

Code	Explanation
0	Organizational maintenance

(4) Recoverability (col. 1d). This column indicates whether unserviceable items should be returned to the responsible commodity command for recovery or salvage. When no code is indicated, the item will be considered expendable and not recoverable. Recoverability code in this list is:

Code	Explanation
	repairable at direct and gen- eral maintenance activities and are normally furnished
	by supply on an exchange basis.

- b. Federal Stock No. (Col. 2). This column indicates the Federal stock number which has been assigned by the Cataloging Division, Defense Logistics Services Center.
- c. Description (Col. 3). This column indicates the Federal item name (shown in capital letters) and any additional description required by supply operations.

The abbreviation "w/e" (with equipment) when used as a portion of the nomenclature, indicates that the end item (major item) includes equipment and repair parts issued with the item. The commodity command or manufacturer's part number is also included for reference.

- d. Unit of Issue (Col. 4). This column indicates the quantity to be requisitioned.
- e. Quantity Authorized (Col. 5, Section II). This column indicates the quantity of the listed item authorized for stockage to constitute the prescribed load.
- f. Quantity Incorporated in Unit (Col. 5, Section III). This column indicates the total number of times the listed item is used in the end item (major item). Where no quantity is shown, reference should be made to the first appearance of the item as indicated in the "description" column.
- g. 15-Day Maintenance Allowance Per Equipment Density Spread (Col. 6, Section III).
 - (1) These columns list allowances which are based on the latest mortality data and are the estimated average quantity required for organizational maintenance to provide maintenance and supply support for selected equipment density spreads for a 15-day period under combat conditions.

Example 1: If the number of equipments supported is 5 the quantitative allowance would be selected from column 6(a) (1-6 equipments).

- (2) The quantitative allowance determined by (1) above constitutes one prescribed load for a 15-day period. This quantity must be on hand or on order at all times.
- (3) Units and organizations authorized additional prescribed loads will multiply the number of equipments supported by the number of prescribed loads and then use the appropriate equipment allowance column. An exception is made for those units and organizations required to have on hand, box or packaged prescribed load(s) pursuant to a special mission assignment. Such prescribed load(s) will be computed or selected separately from quantities authorized for stockage at permanent station.

Example 2: If the number of equipments supported is 5 and the number of prescribed loads is 2, the computation would be $5 \times 2 = 10$. The quantitative allowance would be selected from column 6(b) (7-20 equipments).

- (4) When an allowance is inclosed in parentheses, the item is designated as a "combat essential item of critical nature" and must be stocked at all times.
- (5) Subsequent changes to allowances will be limited as follows:
 - (a) No decrease in the stated quantity of Combat Essential Items is authorized.
- (b) Decrease in the stated quantity, other than Combat Essential Items, are authorized to a minimum quantity of one.

- (c) Increase in the stated quantity are authorized for all items when justified by demand and usage experience.
- (d) Detailed procedures for performing these adjustments are prescribed in AR 735-35.
- (e) No change in the range (list of items contained herein) is authorized. If additional items are considered necessary, a recommendation should be forwarded to the preparing agency for exceptions or revision to the allowance list.
- h. Illustration (Col. 6, Section II and Col. 7, Section III). This column indicates the figure number of the illustration that depicts the listed item. When more than one item appears on an illustration, the item number is also indicated.

4. Abbreviations and Symbols

a. Abbreviations.

blk-oxide fin	black oxide finish
cal	caliber(s)
cd-pltd	cadmium-plated
cham	chamfer
entr	container
dia	diameter
dr	drum
ext-teeth	external teeth
fl-hd	flat head
fl-fil-hd	flat fillister head
fl-pt	flat point
gal	gallon(s)
hd	head
hdl	handle(d)
hex-type	hexagon type
in	
int-teeth	internal teeth
lb	pound(s)

lg	long (length)
max	maximum
min	minimum
NF	American National Fine Thread
No	number(s)
o/a	over-all
od	outside diameter(s)
OZ	ounces
phos-ctd	phosphate-coated
qt	quart(s)
rd	round
S	steel
spl	spool
stk	stock
thk	thick(ness)
UNF	Unified Fine Thread
W	wide, width
w/	with
w/e	with equipment
b. Symbols.	
*	Indicates repair parts which may be required
	to perform authorized maintenance but
	not authorized for stockage in the prescribed
	load. These parts are to be requisitioned,
	as required, for immediate use only.
()	Allowances inclosed in parentheses are
	"combat essential items". These items
	are of a critical nature and must be stocked
	at all times.
AR	Indicates item is to be requisitioned as required.
LAW	Weapons lubricating oil
P-C-111A	Carbon removing compound
PD 126	Solvent cleaning compound
PL special	General purpose lubricating oil
SD	D 1
ממ	Dry cleaning solvent

5. Suggestions and Recommendations

The direct reporting, by the individual user, of errors, omissions, and recommendations for improving

this manual is authorized and encouraged. DA Form 2028 (Recommended Changes to DA Publications) will be used for reporting these improvements. This form will be completed in triplicate, using pencil, pen, or typewriter, and will be forwarded direct to Commanding General, U.S. Army Weapons Command, ATTN: AMSWE-SMM-P, Rock Island Arsenal, Rock Island, Ill. 61202.

SECTION II BASIC ISSUE ITEMS

(1)			(2)	(3)	(4)	(5)	(6)
Source, maintenance, and recoverability code					Quan-	Illustration		
(a) (b) Iate- riel umer- ical code	Main-		Federal stock No.	Description	Unit of issue	tity au- thor- ized	Figure No.	(b) Item No.
				MAJOR ITEMS The major items listed below are req-				
		R	1005-672-1640	uisitioned for initial issue only. MACHINE GUN, CALIBER .30: M1917A1 Browning, w/e (6721640).	1		1	
1		R	1005-672-1643	MACHINE GUN, CALIBER .30: M1919A4 Browning, flexible, w/e (6721643).	1		2	

R , 1005-672-164		1		3
R 1005-611-600	M1919A6 Browning, w/chrome plated	1		
R 1005-673-418	trunnion, block, w/e (8429944). MOUNT, TRIPOD, MACHINE GUN: cal .30, M1917A1, w/e (6734188).	1	-	4
R 1005-322-971		1		5
R 1090-317-242				6
	COMPONENTS OF MAJOR ITEMS			
	The items listed below are issued as components of the major items for initial issue. Replacement items will			
	be requisitioned separately under their individual stock numbers.			
	MACHINE GUN, CALIBER .30: M1917A1 Browing (7142391). MACHINE GUN, CALIBER .30:			
	M1919A4 BROWNING, flexible (7142393).			

	(1)			(2)	(3)	(4)	(5)	(6	i)
Source, maintenance, and recoverability code					Quan-	Illustration			
(a) Materiel numer- ical code	M ource na	(c) (ain- te- ance evel	(d) Re- cover- ability	Federal stock No.	Description	Unit of issue	tity au- thor- ized	(a) Figure No.	(b) Item No.
					MACHINE GUN, CALIBER .30: M1919A6 Browning (7142395). MOUNT, TRIPOD, MACHINE GUN: cal .30 M1917A1 (6507371). MOUNT, TRIPOD, MACHINE GUN: cal .30, M2 (6507052). MOUNT, TRIPOD, MACHINE GUN—RIFLE: M74 (7146253). REPAIR PARTS FOR: MACHINE GUN, CALIBER .30: M1917A1 BROWNING				

P1	0	 1005-653-5388	BARREL: machine gun (6535388)	1	1	14	2
			MACHINE GUN, CALIBER .30: M1919A4 BROWNING				
PI	О	 1005-714-8399	BARREL ASSEMBLY: (7148399)	1	1	16	2
			MACHINE GUN, CALIBER .30: M1919A6 BROWNING				
Pi	0	 1005-714-8400	BARREL ASSEMBLY: (7148400)	1	1	18	2
			MOUNT, TRIPOD, MACHINE GUN: CAL .30, M1917A1				
			(NONE AUTHORIZED)				
			MOUNT, TRIPOD, MACHINE GUN: CAL .30, M2		:		
			(NONE AUTHORIZED)				

(1)		(2)	(3)	(4)	(5)	(6	i)
Source, maintenance, and recoverability code					Quan-	Illustration		
(a) (b) Materiel numerical code	(c) Mainte- nance level	(d) Re- cover- ability		Description	Unit of issue	tity au- thor- ized	(a) Figure No.	(b) Item No.
				MOUNT, TRIPOD, MACHINE GUN—RIFLE: M74 (NONE AUTHORIZED) TOOLS AND EQUIPMENT FOR MACHINE GUN, CALIBER .30: M1917A1 BROWNING MACHINE GUN, CALIBER .30: M1919A4 BROWNING				

		MACHINE GUN, CALIBER .30: M1919A6 BROWNING	10			
	1005-556-4174	BRUSH, CLEANING, SMALL ARMS: bore (5564174).	1	4	7	1
	1005-691-1381	BRUSH, CLEANING, SMALL ARMS: chamber (7790582).	1	1	7	2
	1005-555-9762	CASE: steam condensing device, cal .30 (5559762) (M1917A1 only).	1	1	8	1
	1005-550-6573	CASE, SMALL ARMS CLEANING ROD: cal .30, M1 (5506573).	1	1	7	3
R	1005-653-0780	COVER: machine gun, cal .30, M7 (6530780) (M1917A1 only).	1	1	8	2
R	1005-653-1749	COVER: mach gun, cal .30, M13 (6531749) (M1919A4 only).	i	1		
	1005-669-3026	COVER: spare barrel (5593026)	i	i	7	4
	1005-653-5394	DEVICE: steam condensing (6535394) (M1917A1 only).	1	1	8	3
	1005-555-9696	ENVELOPE: spare parts, M1, 4 X 3 (5559696).	1	1	7	5
	4933-652-9950	EXTRACTOR, RUPTURED CAR- TRIDGE CASE: (7790352).	1	1	7	6
	1005-716-2298	FLASH HIDER: cal .30, M8 (7162298) (M1917A1 only).	1	1	8	5

(b)	(c)		Federal stock No.		Unit	Quan-	Illustr	ation
e-		(d)	Endoval atook No		- Hinit I	de i bas		
l l	200		rederal stock No.	Description	of issue	au- thor-	(a)	(b)
e		Re- cover- ability				ized	Figure No.	Item No.
			1005-049-9210	FLASH HIDER: M6 (5750054) (M1919A4 only).	1	1	9	1
			1005-731-3084	HANDLE: carrying (7313084) (M1917A1 only).	1	1	8	4
			1005-731-2973	HANDLE ASSEMBLY: carrying (7312973) (Equipment for M1919A4 only).	1	1	9	2
			1005-650-8237	ROD, CLEANING, SMALL ARMS:	1	1	7	7
2	-			TECHNICAL MANUAL, TM 9 1005-212-12P.	1	1		
			4933-556-8334	WRENCH, COMBINATION: M6 (5568334).	1	1	7	8
				1005-049-9210 1005-731-3084 1005-731-2973 1005-650-8237	1005-049-9210 FLASH HIDER: M6 (5750054) (M1919A4 only). 1005-731-3084 HANDLE: carrying (7313084) (M1917A1 only). HANDLE ASSEMBLY: carrying (7312973) (Equipment for M1919A4 only). ROD, CLEANING, SMALL ARMS: M1 (6508237). TECHNICAL MANUAL, TM 9 1005-212-12P. 4933-556-8334 WRENCH, COMBINATION: M6	1005-049-9210 FLASH HIDER: M6 (5750054) 1 (M1919A4 only). 1005-731-3084 HANDLE: carrying (7313084) (M1917A1 only). 1005-731-2973 HANDLE ASSEMBLY: carrying (7312973) (Equipment for M1919A4 only). 1005-650-8237 ROD, CLEANING, SMALL ARMS: M1 (6508237). TECHNICAL MANUAL, TM 9 1 1005-212-12P. 4933-556-8334 WRENCH, COMBINATION: M6 1	1005-049-9210 FLASH HIDER: M6 (5750054) 1 1 (M1919A4 only). 1005-731-3084 HANDLE: carrying (7313084) (M1917A1 1 1 only). 1005-731-2973 HANDLE ASSEMBLY: carrying 1 (7312973) (Equipment for M1919A4 only). 1005-650-8237 ROD, CLEANING, SMALL ARMS: 1 1 M1 (6508237). TECHNICAL MANUAL, TM 9 1 1 1005-212-12P. 4933-556-8334 WRENCH, COMBINATION: M6 1 1	1005-049-9210 FLASH HIDER: M6 (5750054) 1 1 9 (M1919A4 only). 1005-731-3084 HANDLE: carrying (7313084) (M1917A1 1 1 8 only). 1005-731-2973 HANDLE ASSEMBLY: carrying 1 1 9 (7312973) (Equipment for M1919A4 only). 1005-650-8237 ROD, CLEANING, SMALL ARMS: 1 1 7 M1 (6508237). TECHNICAL MANUAL, TM 9 1 1 1005-212-12P. 4933-556-8334 WRENCH, COMBINATION: M6 1 1 7

	MOUNT, TRIPOD, MACHINE GUN CAL .30, M1917A1				
1005-557-3157	BAG, HAND TOOLS: carrying (5573157).	1	1	10	1
1005-650-7513	COVER: cradle, M1 (6507513)	1	1	10	2
4933-516-5441	WRENCH: combination, M5 (5165441).	1	1	10	3
5120-516-3925	WRENCH: elevating mechanism, M8 (5163925).	1	1	10	4
	MOUNT, TRIPOD, MACHINE GUN: CAL .30, M2			ı	
1005-659-1428	COVER, TRIPOD MOUNT: (6591428)	1	1	11	
	MOUNT, TRIPOD, MACHINE GUN—RIFLE: M74				
1005-557-3157	BAG, HAND TOOLS: (5573157)	1	1	12	1
1010-714-8796	COVER, CRADLE: (7148796)	1	1	12	2
5120-198-5392	KEY, SOCKET HEAD SCREW: hex- type, $\frac{5}{32}$ in. across flats, L-type hdl, $2\frac{1}{2}$ lg (41-W-2451).	1	1	12	3

(1)	(2)	(3)	(4)	(5)	(6))
Source, maintenance, and recoverability code (a) (b) (c) (d)	Federal stock No.	Description	Unit of	Quan- tity au-	Illustr:	ation (b)
Materiel numerical code (b) (c) (d) Main- te- nance cover- level ability	rederal stock 140.		issue	thor- ized	Figure No.	Item No.
		MISCELLANEOUS MATERIAL				
		The items listed under subheadings below are not issued with the gun, but are requisitioned and issued in accordance with TOE, TA or as otherwise authorized.				
1		AMMUNITION				
		Ammunition for use with these guns is shown in SM 9-5-1305.				
		ARTICLES FOR INSTRUCTIONAL PURPOSES		,		

	The following items WILL NOT BE TAKEN into the field, upon permanent change of station, or into the Theater of Operations. Units will turn in all equipment to the Com- manding Officer of the station from	
	which it departs. The receiving officer will make a report to the Army Commander without delay, showing number, type, and condition of items received.	
1005-040-2889	FIRING ATTACHMENT, BLANK AMMUNITION: M3A1 (8412112) (M1917A1 only) (One per gun when used for training purposes).	1
1005-040-2888	FIRING ATTACHMENT, BLANK AMMUNITION: M6 (8412139) (M1919A4 only) (One per gun when used for training purposes).	1
1005-716-2790	FIRING ATTACHMENT, BLANK AMMUNITION: cal .30, M9 (7162790) (M1919A6 only) (one per gun when used for training purposes).	1

	(1	l)		(2)	(3)	(4)	(5)	(6	3)
	ce, main coverab						Quan-	Illustr	ration
(a) Materiel numerical code	(b)		(d) Re- cover- ability	Federal stock No.	Description	Unit of issue	tity au- thor- ized	(a) Figure No.	(b) Item No.
					GRAPHIC TRAINING AID, 9-4 (M1917A1 only). GRAPHIC TRAINING AID, 9-615	1			
			R	1005-678-7369	(M1919A4 and M1919A6). GUN, SUBCALIBER, CALIBER .22: M3, w/e (6787369) (For allowances see ORD 7 portion of SNL A-48) (M1917A1 only).	1			
			R	1005-678-7370	GUN, SUBCALIBER, CALIBER .22: M4, w/e (6787370) (For allowances see ORD 7 portion of SNL A-48) (M1919A4 only).	1			




Figure 1. M1917A1 caliber .30 machine gun-right rear view.




Figure 2. M1919A4 caliber .30 machine gun—right rear view.





Figure 3. M1919A6 caliber .30 machine gun—right rear view.



Figure 4. M1917A1 machine gun tripod mount.




Figure 5. M2 machine gun tripod mount.



Figure 6. M74 machine gun—rifle tripod mount.




Figure 7. Tools and equipment for machine guns M1917A1, M1919A4, and M1919A6.




Figure 8. Tools and equipment for machine gun M1917A1.




Figure 9. Tools and equipment for machine gun M1919A4.



Figure 10. Tools and equipment for machine gun tripod mount M1917A1.



Figure 11. Equipment for machine gun tripod mount M2.




Figure 12. Tools and equipment for machine gun—rifle tripod mount M74.

SECTION III REPAIR PARTS AND SPECIAL TOOL LISTS

	(1) (2)			(2)			(5)	(6)				(7)	
Source, maintenance, and recoverability code						Unit	Qty		-day nanc equip ensity	e per omen	t	lli tra	us- tion
(A) ((B)	(C)	(D)	Federal stock No.	Description	of issue	inc unit	A	В	С	D	A	В
nateries numerical code	Source	Maint	Recover- ability					1-6	7-20	21-50	51-100	Figure No	Item No.
					REPAIR PARTS FOR:						l		
					MACHINE GUN, CALIBER .30: M1917A1 BROWNING								
					MAJOR GROUPS, ASSEMBLIES, AND COMPONENT PARTS								
)	P1	o		1005-653-5388 E	BARREL: machine gun (6535388)	_ 1	1	(1)	$ _{(1)}$	(1)	(1)	13	

)=	ě
b	۶
LACO	
6	5
8	-
ã	ï
040040	7
ځ	•
0	4

(1)				(2)	(3)	(4)	(5)		((6)		G	7)
Source, maintenance, and recoverability code				•	Unît	Qty		day nanc equip nsity	e per	t		us- tion	
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	В	-50	D	A	В
Materiel numerical code	Source	Maint level	Recover- ability					1-6	7-20		51-100	Figure No	Item No.
	P1 P	0			HANDLE, BOLT: (6147212) PIN, COTTER: S, phos-ctd, ½ dia, ¾ lg (96906-24665-153).	1	1	(1) 1	(1)	(1) 1	(1) 1	13 13	




Figure 13. Major groups, assemblies, and component parts for machine gun M1917A1.

	(1))		(2)	(3)	(4)	(5)		((3)		(7	')
Source and r		erabi				Unit	Qty		nanc equip	main e per ment spre	t	Illi trat	
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	В	С	D	A	В
Materiel numerical code	Source	Maint	Recover- ability				1	1-6	7-20	21-50	51-100	Figure No.	Item No.
					REPAIR PARTS FOR:								
					CASING AND WATER JACKET GROUP								
	Pı	0		4730-601-7471	BUSHING, MACHINE THREAD: (6017471).	1	1	(1)	(1)	(1)	(1)	14	4.
	P	0		1005-614-7211	CORK: (6147211)	1	. 1	(1)	(1)	(1)	(1)	14	6
	Pl	O .			PAWL, BELT: (6147216)	1	. 1	$\lfloor (1)$	(1)	(1)	(1)	14	2
	P1	0			PIN, BELT HOLDING PAWL: (6147217).	1	. 1	$\mathfrak{i}(1)$	(1)	(1)	(1)	14	
	P1	0			SPRING, HELICAL, COMPRESSION: S, cd-pltd, 0.023 stk size, 0.137 free od,	1		(1)	(1)	(1)	(1)	14	3

			0.650 free o/a lg, 13 coils, belt holding pawl (6147225).								
P1	0	 1005-716-2248	STOP, SHORT ROUND: (7162248)	1	1	ık	*	*	*		
P1	0	 5330-522-0234	YARN: asbestos, 2-ply, dia 18 in., lb spl	1		(1)	(1)	(1)	(1)		
			(898300) (Replacement for PACKING 5022937 and PACKING 5022938).								
M		 	PACKING: machine gun, front (Impro-		AR					14	
M		 	vised from above item) (5022937). PACKING: machine gun, rear (Improvised from above item) (5022938).		AR					14	




Figure 14. Casing and water jacket group for machine gun M1917A1.

	(1))		(2)	(3)	(4)	(5)		(6)		(7)
Source and r		erabi				Unit	Qty		nanc equip	mair e per men spre	t		us- tion
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc unit	A	В	C	D	Λ	В
numerical code	Source	Maint level	Recover- ability					1-6	7 20	21-50	51-100	Figure No.	Item No.
					REPAIR PARTS FOR:								
					MACHINE GUN, CALIBER .30: M1919A4 BROWNING								
					MAJOR GROUPS, ASSEMBLIES, AND COMPONENT PARTS								
	P1	O		1005-714-8399	BARREL ASSEMBLY: (7148399)	1	1	(1)	(1)	(1)	(1)	15	2
	Pl	O		1005-614-7212	HANDLE, BOLT: (6147212)	1	1	(1)	(1)	(1)	(1)	15	1
	P1	O			LOCK, BARREL BEARING: (5170491)_	1	1	(1)	(1)	(1)	(1)	15	4
	Р	О		5315-234-1854	PIN, COTTER: S, phos-ctd, ½ dia, ¾ lg (96906–24665–153).	1	1	1	1	1	2	15	3




Figure 15. Major groups, assemblies, and component parts for machine gun M1919A4.

	(1)		(2)	(3)	(4)	(5)		(6)		(7	7)
ource and r		erabi				Unit	Qty.		-day nanc equip naity	e per	r t	Illo trat	us- tion
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	ine	Λ	В	C	ь	\	13
numerical	Source	Maint	Recover-					1 6	7-20	21-50	51 100	Figure No.	Item No.
				1	REPAIR PARTS FOR:					1			
			1		CASING AND BARREL JACKET GROUP]				
	PI	·O		$ _{1005-614-7216} _{\mathrm{F}}$	PAWL, BELT: (6147216)	1,	1	(1)	(1)	(1)	(1)	16	
	P1	()		1005-614-7217 F	PIN, BELT HOLDING PAWL: (6147217).	1,	1	(1)	(1)	(1)	(1)	16	
	P1	0		5305-501-3258 S	SCREW, MACHINE: 8, 0.370 in. min dia of hd, 0.373 in. max dia of hd (5013258).		1	1	1	1	1	16	
	P1	О		1005-614-7225 8	SPRING, HELICAL, COMPRESSION: S, belt holding pawl (0.023 dia stk, 0.15 od, 13 coils) (6147225).	1	1	(1)	(1)	(1)	(1)	16	




Figure 16. Casing and barrel jacket group for machine gun M1919A4.

(1)	(2)	(3)	(4) }	(5)		(61		(*	7)
Source, maintenance, and recoverability code	1		Witness 1	0		-day nanc equip ensity	e per	1		us- tion
$(A) = (B) \frac{1}{2} (C) \frac{1}{2} (D)$	Federal stock No.	Description	of issue	inc	A	В	C	1)	٨	13
Materiel numerical code Source Maint level Recover- ability					9 -	7 20	21.50	51 100	Figure No.	Item No.
, i		REPAIR PARTS FOR:								
[MACHINE GUN, CALIBER .30: M1919A6 BROWNING			[
	1 1	MAJOR GROUPS, ASSEMBLIES, AND COMPONENT PARTS			-	1				
P1 () P1 () [P1 () [1005-614-7212 H 1005-731-2973 H	BARREL ASSEMBLY: (7148400)		1 1 1 1	(1) (1) * (1)	$\begin{pmatrix} (1) \\ (1) \\ * \\ (1) \end{pmatrix}$	(1) (1) * (1)	(1) (1) * (1)	17 17 17 17	1

-	
-	
$\overline{}$	
0	
\circ	
N	
50	
1	
C	

	(1	}		(2)	(3)	(4)	(5)		(6)		(7)
Source and r		erabi				Unit	Qty		nanc	main e per omen spre	t		us- tion
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	ine unit	A	В	C	D	A	В
Materiel numerical s code	Source	Maint	Recover-					1-6	7-20	21–50	51-100	Figure No.	Item No.
	P	0		5315-234-1854	PIN, COTTER: S, phos-ctd, ½ dia, ¾ lg (96906–24665–153).	1	1	1	1	1	2	17	3
	P1	0		5340-716-2161	RING: retaining (7162161)	1	i	(1)	(1)	(1)	(1)	17	4




Figure 17. Major groups, assemblies, and component parts for machine gun M1919A6.



(1)	(2)	(3)	(4)	(5)		(6)		(7)
Source, maintenance, and recoverability code			Unit	Qty		-day nanc equip nsity	e per	r t		us- tion
(A) (B) (C) (D)	Federal stock No.	Description	of issue	inc	A	В	C	D	A	В
Materiel numerical code Source Maint level Recoverability	t				1 1-6	7-20	21-50	51-100	Figure No.	Item No.
		REPAIR PARTS FOR:								
, 1		MACHINE GUNS, CALIBER .30, M1917A1, M1919A4 AND M1919A6								
1		BOLT GROUP								
P1 O	1005-562-1076 E	EXTRACTOR, SMALL ARMS CARTRIDGE: (5621076).	1	1	(1)	(1)	(1)	(1)	18	1
P1 O	1005-613-1317 L	EVER, COCKING: (6131317)	1	1	(1)	(1)	(1)	(1)	18	5
P1 O	1005–550–9186 ¹ F	PIN, FIRING: S, phos-ctd, 0.075 max striking end dia, 4.795 max $\sigma/a \lg (5509186)$.	1	1	(1)	(1)	(1)	(1)	18	8

Pt O	5315 502-0567 PIN, GROOVED, HEADED: fl- phos-ctd, 0.205 shank dia, 1.37		1 (1) (1) (1) (1) 18	S 4
Di ()	lg (5020567). 1 1005-614-7222 ROD ASSEMBLY, DRIVING S	PRING: 1	1 (1) (1) (1) (1)	8 2
P1 O	(6147222).			
PLO	1005-556-4137 SEAR: (5564137)	1	-1 ₁ (1)	
P1 0			-1 (1) (1) (1) (1) $= 13$	8 3
	S, cd-pltd, 0.045 stk size, 0.390			1
	153% free o/a lg, 103 coils,	driving		
	(6212654).	l.		
Pi O	1005-613-1265 SPRING, SEAR: (6131265)	1	$1 \left \begin{array}{c c} 1 \end{array} \right \\ 1 \left \begin{array}{c c} 1 \end{array} \right \left \begin{array}{c c} 1 \end{array} \right \left \begin{array}{c c} 1 \end{array} \right \\ 1 \left \begin{array}{c c} 1 \end{array} \right \\ 1 \left \begin{array}{c c} 1 \end{array} \right \\ 1 \left \begin{array}{c c} 1 \end{array} \right \left $	8 6




Figure 18. Bolt group for machine guns M1917A1, M1919A4, and M1919A6.

	(1))		(2)	(3)	(4)	(5)		(6)		(7	")
Source and r	, mai ecov cod	erabil	ince, lity			Unit	Qty	ı	nanc	nnain e per onten spre	t	Illi	
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	В	С	р	A	В
Materiel numerical code	Source	Maint level	Recover- ability			.		1-6	7-20	21-50	51-100	Figure No.	Item No.
					REPAIR PARTS FOR:			ì					
					LOCK FRAME GROUP								
	P1	0		1005-613-1253	PIN ASSEMBLY: accelerator and breech lock (6131253).	1	1	(1)	(1)	(1)	(1)	19	6
	P1	0		5315-502-0503	PIN, SHOULDER, HEADLESS: cham phos-ctd, 0.135 smaller shank dia, 0.200 larger shank dia, 0.250 shoulder dia 1.310 o/a lg (5020503).)		(1)	(1)	(1)	(1)	19	3
	P1	0		1005-613-1251	PLUNGER, BARREL EXTENSION (6131251).	: 1		(1)) (1)	(1)	(1)	19	1

	(1)			(2)	(3)	(4)	(5)		(6)		(7	7)
Source, and re		rabi				Unit	Qty		-day nanc equip nsity	e pe omen	r	Illi	
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	B	С	D	A	В
Materiel numerical code	Source	Maint	Recover- ability					1-6	7-20	21-50	51-100	Figure No.	Item No.
- 1	P1	()		1005-614-7231 S	SPRING, HELICAL, COMPRESSION: S cd-pltd, 0.031 stk size, 0.220 free od, 0.280	'	1	(1)	(1)	(1)	(1)	19	4
1	P	0		1005-614-7223 S	free o/a lg, 4 coils, trigger pin (6147231). PRING, HELICAL, COMPRESSION S, cd-pltd, 0.046 stk size, 0.280 min id 0.372 od, 3¾ free o/a lg, 26 coils, barre	,	1	(1)	(1)	(1)	(1)	19	
	P1	O		1005–513–5057 S	plunger (6147223) (For M1917A1 only) SPRING, HELICAL, COMPRESSION S, 0.047 dia stk, 0.387 od, 24 coils barrel plunger (5135057) (For M1919A4 and M1919A6).	1	1	(1)	(1)	(1)	(1)	19	2
	P1	0		1005-342-1100	TRIGGER: (8407769)	1	1	(1)	(1)	(1)	(1)	19	5




Figure 19. Lock frame group for machine guns M1917A1, M1919A4, and M1919A6.

	(1)		(2)	(3)	(4)	(5)		((6)		(7	7)
Source and r		erabi				Unit	Qty	Ī	-day nanc equip ensity	e per		Ill: trat	us- tion
(A)	(B)	((*)	(D)	Federal stock No.	Description	of issue	ine unit	A	В	С	a	A	В
Materiel numerical code	Source	Maint level	Recover- ability					16	7-20	21-50	51-100	Figure No.	Item No.
					REPAIR PARTS FOR:								
					BARREL EXTENSION GROUP								
	P1	0		1005-613-1253	PIN ASSEMBLY: accelerator and breech lock (6131253). (For authorized allowances see this		1					20	1
	Pi	О		1005-614-7230	item under Lock Frame Group). SPRING, BARREL LOCKING: (6147230)_	1	1	(1)	(1)	(1)	(1)	20	2




Figure 20. Barrel extension group for machine guns M1917A1, M1919A4, and M1919A6.

(1)	(2)	(3)	(4)	(5)		(6	6)		(7	7)
Source, maintenance, and recoverability code			Unit	Qty		day nanc equip nsity	e per	t		us- tion
(A) (B) (C) (D)	Federal stock No.1	Description	of issue	ine unit	A	В	C	D	Λ	В
Materiel munerieal code Source Maint level Recover-ability					1-6	7-20	21-50	51-100	Figure No.	Item No.
		REPAIR PARTS FOR:								
		COVER GROUP								
PI (0	1005-601-7503 LEV	ER, BELT FEED: (6017503)	1	1	(1)	(1)	(1)	(1)	21	4
P1 O		r, BELT FEED LEVER PIVOT USHING: (5196284).	1	1	(1)	(1)	(1)	(1)	21	10
P1 0		L, BELT FEED: (5508461)	1	1	(1)	(1)	(1)	(1)	21	7
P1 0	1005-613-1255 PIN	: belt feed pawl (6131255)	1	1	(1)	(1)	(1)	(1)	21	
P1 O	ox	GROOVED, HEADED: S, blk- ide fin., fl-hd, 0.257 min dia of hd, 0.261 ax dia of hd (belt feed lever) (5157434).		1	(1)	(1)	(1)	(1)	21	3

P1 [O		5305-558-3689 SETSCREW: sltd, S, phos-ctd, fl-pt, 3 s	1	-1 (1) (1) (1) (1) 2	1 1
		24UNF-3A, 0.235 lg (5196283).		1 1 1 1	
P1 0		1005-613-1262 SLIDE, BELT FEED: (6131262)	1	(1, (1), (1), (1), (1), (2)	lj 5
P1 0		1005-597 0429 SPRING, HELICAL, COMPRESSION:	1	1(1)(1)(1)(1)(1)	1 8
		S, 0.032 stk size, 0.340 free od, 0.780			
		free o/a lg, 6 coils, belt feed-pawl			
		(6147224).			
P1 0		1005-601-7513 SPRING: cover extractor (6017513)	1	-1 (1) (1) (1) (1) 2	1 9
P1 O		5310-013-8528 WASHER, LOCK: S, phos-fin., 0.150 id,	1	-1 (1) (1) (1) (1) 2	1 2
		0.295 od, 0.021 thk (96906–35333–54).			
P1 O		5310-013-8544 WASHER, LOCK: int-teeth, S, phos-ctd,	1	-1 (1) (1) (1) (1) 2	1 11
		3/s bolt size (96906~35333-59).			
			1		




Figure 21. Cover group for machine guns M1917A1, M1919A4, and M1919A6.

	(1)		(2)	(3)	(1)	(2)		•	6)		(7	71
		ntens erabi .e				Unit	Qty			e pe pinen	r it		us- tion
Δ)	(B)	(C)	(D)	Federal stock No.	Description	of 18840	inc	Λ	В	10	Đ	A	В
numerical	Source	Maint level	Recover- ability					1-6	7-20	21-50	51-100	Figure No.	Item No.
					REPAIR PARTS FOR:								
				MO	UNT, TRIPOD, MACHINE GUN: CAL .30, M1917A1								
	PI	0		l l	T, MACHINE: S, hex-hd, %6-18UNF	- 1	1	(1) (1)	(1)	(1)	22	
	P	O		5310-513-9964 NUT	Γ, SLOTTED, HEXAGON: S, %6 UNF-2 (5139964).	1	1	(1) (1	(1)	(1)	22	
	P1	O		5315-013-7195 PIN	, COTTER: S, phos-etd, 1/8 x 11/37195).	4 1	1	(1) (1	(1)	(1)	22	




Figure 22. Repair parts for machine gun tripod mount M1917A1.

	(1)		(2)	(3)	(4)	(5)		((6)		(7)
		ntena erabi le				Unit '	Qty		nanc	ianii re pe pinen r spro	r t		us- tion
_ A)	(B)	(C)	(D)	Federal stock No.	Description	of	unit	Λ	B	C	1)	۱.	В
numerical	Source	Maint level	Recover-					1-6	7-20	21 50	51-100	Figure No.	Item No.
					REPAIR PARTS FOR:	}							
		l .			MOUNT, TRIPOD, MACHINE GUN: CAL .30, M2								
	P1	()			T, MACHINE: S, hex-hd, % 16-18UNF ., 311/2 lg (5139973).	- 1	1	(1)	(1)	(1)	(1)	23	3
	P	()		5310-513-9964 NUT	C, SLOTTED, HEXAGON: 8, pint olt %4-18NF-2, 25/4 thk (5139964).	e i	1	(1)	(1)	(1)	(1)	23	2
	P1	0		5315-013-7195 PIN,	COTTER: S, phos-etd, 1/8 dia, 1/3 (137195).	á 1	1	(1	(1)	(1)	(1)	23	1

	(1)		(2)	(3)	(4)	(5)		(6)		("	7)
Source, and re		erabi				Unit	Qty		nanc equip	main e per men spre	t		us- tion
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	В	С	D	A	В
Materiel numerical code	Source	Maint level	Recover-					1-6	7-20	21-50	51-100	Figure No.	Item No.
	Pi	O		5305-513-9989	SCREW, MACHINE: S, button hd, phos-ctd, No. 10 (0.190) -32NF-2A, ½ lg (5139989).	1	1	(1)	(1)	(1)	(1)		
	PI	О		5310-012-5754	WASHER, LOCK: S, ext-teeth, phos-ctd, No. 12 (0.216) screw size (125754).	1	1	*	*	*	*		




Figure 23. Repair parts for machine gun tripod mount M2.



(1)	(2)	(3)	(4)	(5)		((6)		(7)
Source, maintenance, and recoverability code			Unit	Qty		-day nanc equip ensity	e per omen	t	III trai	us- tion
(A) (B) (C ₂ (D)	Federal stock No.	Description	of issue	ine	A	В	С	·D	A	В
Materiel mune ical code Source Maint level Recoverability					1-6	7-20	21-50	51-100	Figure No.	Item No.
		REPAIR PARTS FOR:								
		MOUNT, TRIPOD, MACHINE GUN—RIFLE: M74					:			
		(NONE AUTHORIZED)								
	RO	DD, CLEANING, SMALL ARMS: M1								
Pi 0	1	ARMS CLEANING ROD: (6017660).	1]]	aje.	aje	*	*	7	7A

	TOOLS AND EQUIPMENT AUTHORIZED FOR UNIT REPLACEMENT		١	
i	MACHINE GUN, CALIBER .30: M1917A1 BROWNING			
	MACHINE GUN, CALIBER .30: M1919A4 BROWNING	1	ļ	
	MACHINE GUN, CALIBER .30: M1919A6 BROWNING		1	
	1005-556-4174 BRUSH, CLEANING, SMALL ARMS: bore (5564174).	1(1) (1) (2) (4)	7	1
	1005-691-1381 BRUSH, CLEANING, SMALL ARMS; chamber (7790582).	$1 = \frac{1}{\left (1) \right (1) \left (1) \right (2)}$	7	2
	1005-555 9762 CASE: steam condensing device, cal .30 (5559762) (M1917A1 only).	1 1 1 1		1
	1005-550-6573 CASE, SMALL ARMS CLEANING ROD: cal .30, M1 (5506573).	1 * * * * *		3
R	1 00 35	1 sk sk sk sk	8	2

	(I)		(2)	(3)	(4)	(5)		((3)		(7)
Source and 1	e, ma recov roc	erabi	ance, lity	Federal stock No.	Description	Unit of	Qty		nanc equip	main e per men spre	t		lus- tion
(A)	(P)	(C)	(D)			issue	unit	A	В	C	D	A	В
Materiel numerical code	Source	Maint	Recover- ability					1-6	7-20	21-50	51-100	Figure No.	Item No.
		R		1005-653-1749	COVER: mach gun, cal .30, M13 (6531749) (M1919A4 only).	1		*	*	*	*		
				1005-559-3026	COVER: spare barrel (5593026)	1		*	*	*	*	7	4
				1005-653-5394	DEVICE: steam condensing (6535394) (M1917A1 only).	1		1	1	1	2	8	3
			1	1005-555-9696	ENVELOPE: spare parts, M1, 4 X 3 (5559696).	1		*	*	aje	*	7	5
				4933-652-9950	EXTRACTOR, RUPTURED CARTRIDGE CASE: (7790352).	1		(1)	(1)	(1)	(1)	7	6
				1005-716-2298	FLASH HIDER: cal .30, M8 (7162298) (M1917A1 only).	1		(1)	(1)	(1)	(1)	8	5

1005-049-9210	FLASH HIDER: M6 (5750054) (M1919-A4 only).	1	(1)	(1)	(1)	(1)	9	1
1005-731-3084	HANDLE: carrying (7313084) (M1917A1 only).	1	(1)	(1)	(1)	(1)	8	4
1005-731-2973	HANDLE ASSEMBLY: carrying (7312973) (Equipment for M1919A4 only).	1	*	*	*	*	9	2
1005-650-8237	ROD, CLEANING, SMALL ARMS: M1 (6508237).	1	. (1)	(1)	(1)	(1)	7	7
4933-556-8334		1	_ (1)	(1)	(1)	(1)	7	8
	MOUNT, TRIPOD, MACHINE GUN: CAL .30, M1917A1		,					
	BAG, HAND TOOLS: carrying (5573157).	1	_ (1)					1 2
	COVER: cradle, M1 (6507513)	1		1		$\begin{vmatrix} 1 \\ (1) \end{vmatrix}$	$\frac{10}{10}$	
	WRENCH: combination, M3 (5163441). WRENCH: elevating mechanism, M8 (5163925).	1			1	(1)		4
	MOUNT, TRIPOD, MACHINE GUN: CAL .30, M2							
1005-659-1428	COVER, TRIPOD MOUNT: (6591428).	1	*	*	*	*	11	

	(1)		(2)	(3)	(4)	(5)		(ß)		(7	7)
Source and t		erabi				Unit	Qty.		nanc	main e per ment spre	t.	Illi trat	
(A)	(E)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	P	С	D	A	В
Materiel numerical code	Source	Main: level	Recover-					1-6	7-20	21-50	51-100	Figure No.	Item No.
				1010-714-8796	MOUNT, TRIPOD, MACHINE GUN—RIFLE: M74 BAG, HAND TOOLS: (5573157)	S		*	*	(1)	*	12 12 12	2

(FOR ARMORERS USE)						
The 15-day level is not applicable.						
MACHINE GUN, CALIBER .30: M1917A1 BROWNING						
MACHINE GUN, CALIBER .30: M1919A4 BROWNING						
MACHINE GUN, CALIBER .30: M1919A6 BROWNING						
1005-650-7349 ROLL, ORDNANCE WEAPONS SPARE 1 PARTS: M13 (6507349).	_ 2	2	2	2	24	1
1005-288-3565 SWAB, SMALL ARMS CLEANING: Pkg	(1) (1)	(I)	(1)		
cotton, 2½ sq (1000 in pkg) (5019316). WRENCH, SOCKET: barrel bearing plug, cal.30(6147277)(M1919A4 and M1919A6 only).	(1) (1)	(1)	(1)	24	2
MOUNT, TRIPOD,						
MACHINE GUN: CAL. 30 M1917A1						
(NONE AUTHORIZED)						

	(1)		(2)	(3)	(4)	(5)		(6)		(7)
Source and r		erabi				Unit	Qty		nanc	main e per pmen spre	*	Ill tra	lus- tion
(A)	(P)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	В	С	D	A	В
Materiel numerical code	Source	Maint level	Recover- ability					1-6	7-20	21-50	51-100	Figure No.	Item No.
					MOUNT, TRIPOD, MACHINE GUN: CAL .30, M2								
					(NONE AUTHORIZED)								
					MOUNT, TRIPOD, MACHINE GUN—RIFLE: M74								
					(NONE AUTHORIZED)								



Figure 24. Tools and equipment.

	(1)		(2)	(3)	(4)	(5)	(6)			(7)	
Source and		rerabi				Unit	Qty		-day nanc equip ensity	e per	t		lus- tion
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	В	C	D	A	В
Materiel numerical eode	Source	Maint	Recover- ability					1-6	7-20	21-50	51-100	Figure No.	Item No.
					MATERIAL REQUIRED FOR COLD WEATHER OPERATIONS								ľ
		1			The following item will be requisitioned as required for use in cold weather operation.								
					COOLANT (FOR M1917A1 ONLY)								
3			ļ ļ	6850-243-1992 6850-243-1993		1 1			f				

3	6850-224-8730 5 gal entr	1			1
3	6850–243–1990 55 gal dr				1
	CLEANING AND PRESERVING MATERIALS			,	. 1
111	The following items are requisitioned as required.			1	
5	2 :8020-244-0153 BRUSH, ARTISTS: metal, ferrule, flat, chisel edges, 7/6 w, 11/8 lg exposed bristle (96906-16840).	1			
10	7920-205 2401 BRUSH, CLEANING, TOOL AND PARTS: rd, 100 percent tampico fiber, 1½6 at ferrule brush dia, 2½ clear of block brush lg (96906-16746-29).	1			
3	6850-620-0610 CARBON REMOVING COMPOUND: (P-C-111A) (5 gal can).	1			
	CLEANING COMPOUND, SOLVENT: small arms bore cleaner, solution type (PD 126).	1			
3	. 6850-682-6835 2 oz can	1			
3	6850-682-6834 6 oz can	1			
3	6850-682-6833 1 qt can 1 gal can	1			
0[, -	1 80 (401)	7.1	[1		1

	(1)		(2)	(3)	(4)	(5)		(6)		(7)
Source and r		erabi				Unit	Qty		-day nanc equip ensity	e per omen	t		us- tion
(A)	(B)	(C)	(D)	Federal stock No.	Description	of issue	inc	A	В	C	D	A	В
Materiel numerical code	Source	Maint level	Recover-					1-6	7-20	21-50	51-100	Figure No.	Item No.
3				5350-221-0872	CLOTH, ABRASIVE: crocus, ferric oxide and quartz, jean-cloth-backing, closed coating, 9 w, 11 lg (42-C-20420-50).	1							
3				6850-281-1985	DRY CLEANING SOLVENT: (SD) (1 gal can).	1							
					LUBRICATING OIL, GENERAL PURPOSE: (PL special)								
10				9150-273-2389		1							
10		1		9150-231-6689	1 qt can	I							

10 9150-292-9689 LUBRICATING OIL, WEAPONS: (LAW) for below zero operations (1 qt can). 7920-205-1711 RAG, WIPING: cotton, for general purpose use (50 lb bale) (96906-16746-131).	1		
---	---	--	--

SECTION IV MAINTENANCE ALLOCATION CHART

1. Purpose

To allocate specific maintenance operations to the proper maintenance level on the basis of time, tools and skills normally available to various maintenance levels in combat situations and influenced by maintenance policy and sound maintenance practices.

2. Explanations and Definitions

The maintenance allocation chart designates overall responsibility for the maintenance function of an end item or assembly. Repair and or overhaul of major assemblies is designated by authority of the Army commander representative, except for the specific repair subfunctions listed in the maintenance allocation charts. Deviation from maintenance operations allocated in the maintenance allocation charts is authorized only upon approval of the Army commander representative.

SÉRVICE REPAIR To clean, preserve, and lubricate.

To restore to a serviceable condition by replacing unserviceable parts or by any other action required utilizing tools, equipment and skills available, to include riveting, straightening, adjusting, etc.



To substitute serviceable assemblies, subassemblies, and parts for unserviceable items.

OVERHAUL

To restore to a serviceable condition by disassembling the item to determine the condition of each of its component parts and reassembling it using serviceable or new assemblies, subassemblies, and parts.

SYMBOL "X"

The symbol "X" placed in the appropriate column indicates the maintenance level responsible for performing that particular maintenance operation, but does not necessarily indicate that repair parts will be stocked at that level. Maintenance levels higher than the level marked by X are authorized to perform the indicated operation.

3. Explanation of Maintenance Levels

0/0	Operator or Crew
0	Organizational
DS	Direct Support
GS	General Support
D	Depot

Maintenance Allocation Chart

(1)	(2)			(3)				
Group	Component and related	Maintenance levels						
No.	operations	O/C	0	DS	GS	D		
	MACHINE GUN, CAL. .30, M1917A1							
1	Back Plate Assembly:							
	Service	x		ĺ	i			
	Repair.		_	X				
	Replace			X				
	Overhaul		-			X		
2	Bolt Group:							
	Service	X						
	Repair_		X					
	Replace			x				
	Overhaul					x		
3	Lock Frame Group:							
	Service	X						
	Repair		x					
	Replace		-	X				
	Overhaul					x		
4	Barrel Extension Group:							
	Service	x		1				
	Repair		x					
	Replace			x				
	Overhaul		_	-		X		
5	Barrel:			1				
	Service	X	i					
	Replace		X	()		
6	Cover and Rear Sight	1	'					
	Group:		1		,			
	Service	X	1					
	Repair		X		1			
	Replace					X		
	Overhaul					x		

(1)	(2)			(3)				
Group	Component and related	Maintenance levels						
No.	operations	O/C	0	DS	GS	1)		
7	Casing, W/Water Jacket Assembly: Service	X						
	Repair		x					
	Overhaul	- ,	Λ		1	X		
	Overnaur					1		
	MACHINE GUN, CAL30, M1919A4							
1	Back Plate Assembly:			1				
	Service	х						
	Repair			l x				
	Replace	1		x				
	Overhaul					X		
2	Bolt Group:							
	Service	x			}	l		
ŀ	Repair.		x	1	1			
1	Replace.			X	i	1		
	Overhaul				(x		
3	Lock Frame Group:							
	Service	x						
	Repair		X					
	Replace			x	4)		
	Overhaul			1		X		
4	Barrel Extension Group:				1	ŧ		
	Service	x			1			
	Repair		x	1	[
	Replace	1	-	х				
	Overhaul					X		
5	Barrel Assembly:							
	Service	X						
	Replace	X	,			4		
						1		

Group No.	Component and related operations	0/C	Main	tenance	levels						
No.	operations	O/C		Maintenance levels							
6	operations		0	DS	GS	D					
	Cover Group:										
-	Service	x			4						
	Repair		X								
	Replace			X	j						
İ	Overhaul					X					
7	Casing Group:										
	Service	x									
	Repair	1	X								
	Overhaul					X					
8	Barrel Jacket Group:										
	Service	x									
	Repair		X								
	Replace				x						
1	Overhaul			_	_	X					
	MACHINE GUN, CAL.										
	.30, M1919A6										
1	Back Plate Assembly:										
-	Service	x		i							
	Repair			×							
	Replace			X							
	Overhaul.					x					
2	Bolt Group:										
_	Service	x									
	Repair		X								
	Replace			X							
	Overhaul					X					
3	Lock Frame Group:					- 1					
"	Service	X									
	Repair		X								
	Replace.			X							
	Overhaul	1		Α.		X					

(I) Group	(2) Component and related	(3) Maintenance levels					
No.	operations	O/C	0	DS	GS	1)	
4	Barrel Extension Group:						
	Service	X					
	Repair		X				
	Replace			X			
	Overhaul					X	
5	Barrel Assembly:						
	Service	X					
	Replace	X					
6	Cover Group:						
	Service	X					
	Repair		X				
	Replace			X			
	Overhaul					X	
7	Casing Group:						
-	Service	X					
	Repair		X				
	Overhaul					X	
8	Barrel Jacket Group:						
	Service						
	Repair		X				
	Replace				X		
	Overhaul					X	
9	Shoulder Stock			1-10			
	Assembly:				- 1		
	Service	x					
	Repair			X			
	Replace			X			
	Overhaul					X	
10	Flash Hider Group:				- 3		
	Service	X					
	Repair			X			
	Replace			X			
	Overhaul					X	

(1)	(2)	(3) Maintenance levels						
Group No.	Component and related operations	O/C	0	DS	GS	D		
11	Bipod Assembly: Service Repair Overhaul			X		X		
12	Carrying Handle Assembly: Service Replace Overhaul		X			X		
	MOUNT, TRIPOD, MACHINE GUN, M1917A1							
1	Cradle Assembly: Service Repair Overhaul	X	x			X		
2	Socket and Leg Groups Service			X		X		
	MOUNT, TRIPOD, MACHINE GUN, M2							
1	Head and Leg Groups: Service Repair Overhaul		X			X		
2	Elevating and Traversing Assembly: Service	X	X					
	ReplaceOverhaul			X		X		

(1)	(2)		Maint	(3) enance	levels	
Group No.	Component and related operations		1			
		O/C	0	DS ———	GS ———	
	MOUNT, TRIPOD,					
	MACHINE GUN—					
	RIFLE, M74					
1	Cradle Assembly					
	Service	X				
	Repair			X		
	Overhaul					X
2	Socket and Leg Groups:					
	Service	x				
	Repair			X		
	Overhaul					X

By Order of the Secretary of the Army:

HAROLD K. JOHNSON, General, United States Army, Chief of Staff.

Official:

J. C. LAMBERT,

Major General, United States Army, The Adjutant General.

Distribution:

Active Army:

Corps (2) USASA (2) USA Corps (2) DCSLOG (1) Div (2) CNGB (1) COMMEL (1) Bde (2) Regt/Gp/BG (2) CofEngrs (1) TSG (1) Bn (2) Co (1) except USAOCDA (2) USCONARC (3) Ord Co (2) Instl (2) except USAMC (5) USAWECOM (60) Ft Meade (3) USAMICOM (2) Svc Colleges (2) Br Sve Sch (2) except USAMUCOM (2) USAECOM (2) USA Ord Sch (50) USA Test Cen (3) USASMCOM (2) USAMOCOM (1) GENDEP (OS) (1) Ord Sec. GENDEP (OS) (1) USASMCOM (2) Ord Dep (OS) (2) USATECOM (2) Army Dep (2) except ARADCOM (2) ARADCOM Rgn (2) Tooele (12) Army Tml (2) OS Maj Comd (2) except USAREUR (3) POE (2) USAOSA (1) USARJ (3) Arsenals (5) OS Base Comd (2) LOGCOMD (2) Springfield Armory (2) Proc Dist (2) MDW (2) Armies (3) except Cen (2) Sixth USA (1) Mil Msn (1)

NG: State AG (3); units—εame as active Army except allowned is one copy to each unit.

USAR: Same as active Army except allowance is one copy to each unit. For explanation of abbreviations used, see AR 320-50.

☆ U.S. Government Printing Office: 1964-750597